

INSRUCIONS RE HALL HEATING TIMER

TO SWITCH HEATING ON:-

Press **BLUE BOOST BUTTON ONCE** to turn on heating for 1HOUR:

OFF TIME will be displayed

Press **BLUE BOOST BUTTON TWICE** to turn heating on for 2 HOURS:

OFF TIME will be displayed

TO SWITCH HEATING OFF:-

Press **BLUE BOOST BUTTON THREE TIMES**

OFF will be displayed