Heating User Guide



Central Heating



Use these to adjust the target temperature between 14 and 20.